



Field Modification

Resin Spots

I. Inspection

- **Freight Damage:** Inspect cartons for obvious damage before accepting and note on delivery ticket.
- **Concealed Damage:** Notify Conwed of any concealed damage within five (5) business days of receipt. Claims beyond five (5) days will be honored at the discretion of Conwed or the freight company.
- Do not install panels of unacceptable quality. Contact your sales representative immediately. Conwed will not be responsible for installation or removal costs of unacceptable panels.

II. Handling & Storage

- Handle individual panels 'on edge' to avoid bending when moving and carrying.
- Store panels on a flat, dry, solid surface. Do not store on edge.
- Take necessary measures to keep panels dry, clean and free from dust. Pay special attention to edges.

III. Instructions

Occasionally a non-standard Z-Clip placement is required. To create a new resin spot to affix an attachment, please follow these instructions.

1. Purchase a 2-part fiberglass resin kit from your local hardware or building supply store. Mix per instructions and try in an inconspicuous area.
2. Mark the required spot carefully.
3. With panel lying flat, apply 4" diameter spots where desired, and allow to set up. Be sure to keep resin edge no less than 2" from edge of panel. The resin should slowly flow into the fibers of the panel.
4. Once the resin has hardened, screw the panel clip into the hardened area using #8 self-drilling screws, being careful not to strip out the screws.

Disclaimer: The following are guidelines given in good faith to help avoid common errors. They are not intended to be a step-by-step list of instructions or a checklist, and it is assumed the installer has general construction knowledge. Conwed bears no responsibility for any installation actions taken or not taken, and is not responsible for installer selection.